MUJI

FACE & NOSE TRIMMER
Model KLC-R820

User' s Manual

●Thank you for your purchase.
●In order to use this product properly, please first read this User's Manual before use.
●Please keep this User's Manual stored in a handy location even after reading it, and refer to it when necessary.

Accessory
Facial hair cutter
Nasal hair cutter
User's Manual (This sheet)

Safety advice ····· 1-2
Part names ····· 3
Attaching/removing the attachment ····· 4
Attaching/removing the blade (facial hair cutter) ····· 4
Inserting the battery ····· 5
How to use ····· 6
Concerning maintenance and storage ····· 7
Note (for Europe) ····· 8

Safety advice

* Prior to use, please thoroughly read and follow these safety instructions.
* The precautions in this User's Manual are listed in order for the product to be used safely and to prevent injuries and material losses to yourself or others.The precautions are divided into 2 categories, "Warning" and "Caution", based on the scale of damage that might occur from incorrect handling. Please follow these precautions as they are all important safety instructions.

⚠ WARNING WARNING indicates a hazard with a medium level of risk which, if not avoided, could result in death or serious injury.

⚠ CAUTION CAUTION indicates a hazard with a low level of risk which, if not avoided, could result in minor or moderate injury.

Meaning of symbols and examples

This symbol indicates prohibited conduct. Details on the prohibited conduct will be drawn and described in and around the symbol. (The symbol on the left indicates "disassembly prohibited")

This symbol indicates compulsory items. Details on the compulsory conduct will be drawn and described in the symbol. (The symbol on the left indicates "unplug from power socket")

* Please keep this User's Manual stored in a handy location even after reading it, and refer to it when necessary.

⚠ Warning

- Do not perform modifications. Do not perform disassembly .
  This may cause fire, electric shock or injury.
- Do not allow children to use unattended, or use within reach of infant' s hands.
  This may cause electric shock or injury.
- Do not use on areas with wounds, eczema, moles, bruises, warts or boils.
  This may cause injury to skin.

⚠ Warning

- Do not use if you are of the following.
  • Prone to allergies or have sensitive skin
  • Severely sunburnt, or having skin problems such as boils or rashes
  • Experienced rashes after using synthetic fiber
  • Experienced shaving rash
  Stop use if skin problems develop during usage.
  This cause of skin problems may also be due to stress, constitution, internal diseases, or cosmetics, so please seek treatment from a doctor.
- When using the product for the first time, conduct a simple shave test.
  If not, it may cause skin problems.
- Do not splash water on the product. Do not use with wet hands.
  This may cause a short-circuit or electric shock.

⚠ Caution

- Do not leave product immersed in water. Do not store in locations with high humidity such as bathrooms.
  This may cause a short-circuit or electric shock.
- Do not drop or knock the product.
  This may cause electric shock or fire.
- Do not use on areas apart from the face, nape of the neck, or nasal hair. Do not use on head or on infants.
  This may cause injury or malfunction.
- Do not press the blade down too strongly against the skin.
  This may cause injury to skin.
- Do not insert the nasal hair cutter deep into the nostrils.
  This may cause nasal injuries.
- Please check the blade condition (deformities, damages) before use.
  This may cause injury to skin.

Part names

KLC-R820

Body



Specifications

Power source	DC1.5V AAA/LR03 Battery x1 (Sold separately)
Size	Approx. 16(W) x 16(D) x 140(H) mm
Product weight	Approx. 20g (facial hair cutter equipped, without batteries)
Accessories	Attachment (facial hair cutter, nasal hair cutter)

Battery life (Estimate)

1 AAA/LR03 battery, if used once a day for 5 minutes, can last approx. 2 weeks.
Varies based on maintenance and surrounding temperature.

Attaching/removing the attachment

■ Attaching
Fit the attachment into the hole on the product body, then push and turn approx. 45° in the direction indicated by the arrow.

■ Removing
Remove by turning the attachment in the direction indicated by the arrow.

Attaching/removing the blade (facial hair cutter)

■ Removing
Remove by sliding the blade release button in the direction indicated by the arrow.

■ Attaching
①Fit the protrusion on the tip of the attachment into the groove on the tip of the blade.
②Slide the blade release button in the direction indicated to fix the blade in place.

Inserting the battery

●Please ensure that the switch is turned off.

⚠ Caution Please wipe the body dry when it is wet.

1 Pull the battery cover in the direction indicated by the arrow.

2 Insert the battery according to the sign in the battery case and reattach the cover.

⚠ Caution
- Do not reverse the negative and positive ends.
- Use only alkaline batteries.
- When there is difficulty cutting the facial hair or the nasal hair, please exchange the battery with a new AAA/LR03 alkaline battery.

⚠ Caution when handling the battery

Please obey the following. If not, these may cause injury or damage to the surroundings due to overheating, rupture or leakage of the battery.
• Use only alkaline batteries
• Obey the cautions labeled on the batteries
• Insert the battery correctly, taking note of the +/- ends
• Remove the used batteries immediately and dispose of it according to your local rules
• Remove the batteries when the product will not be used for a long time
• Only use batteries that are still within their recommended usage period
• Do not throw into fire

How to use

●When using the product for the first time, conduct a simple shave test.

⚠ Caution Please check the blade condition (deformities, damages) before use.

How to shave downy hair

1 Equip the facial hair cutter on the body, and turn the switch on.

2 Gently apply the blade to the skin, and shave against the grain.

1 • Tilt the blade until it is resting against the skin, and move the blade slowly along the shaving area.
• Stretch the skin with your hands or by moving your face for a better shave.
• Change the grip depending on the direction the shaver is moving for an easier shave.

2 • For a closer shave, face the movable blade downwards.
• The blade on the side with the blade release button is the movable blade.

⚠ Caution Do not press the blade down too strongly against the skin.
This may cause injury to skin.

How to shave nasal hair

1 Equip the nasal hair cutter on the body, and turn the switch on.

2 Apply the nasal hair cutter near the entrance of the nostrils, and slowly move the cutter around to shave.

⚠ Caution Do not insert the nasal hair cutter deep into the nostrils.
This may cause nasal injuries.

After use

Turn the switch off and reattach the cap.

Concerning maintenance and storage

●Please ensure that the switch is turned off.

Concerning maintenance

Attachment

①Remove the attachment from the body.
• The facial hair cutter can be cleaned after removing the blade.

②Wash the dirt off with cold or lukewarm water.



Can be washed with warm water. (Below 45°C (113°F))

③After washing, wipe the moisture off with a soft dry cloth.

Body

Wipe the dirt off with a soft dry cloth.

⚠ Caution
- Do not wash while the attachment is still attached to the body.
- Do not use hot water.
- Never use Benzene or paint thinners.

Storage

- Store in a location out of reach of small children.
- Do not store in locations with high humidity such as bathrooms, or in locations exposed to direct sunlight.

This product complies with the EMC requirements of the European Community.

The symbol on the product, packaging, and/or accompanying document indicates that this product should not be disposed with normal household waste. This product shall be taken to the applicable collection point for recycling. The correct disposal of your old product will help prevent potential negative consequences for the environment and human health. For more information about recycling of this product, please contact the shop where you purchased the product, or your local authority.

This symbol on the battery or on the packaging indicates that the battery provided with this product shall not be treated as household waste.
Please inform yourself about the local rules on separate collection of batteries. The correct disposal of batteries helps to prevent potentially negative consequences for the environment and human health.

MEMO